

---

## Installation Instructions for: Front Axle Six Shooter covers

### **Package Contents**

- Chrome Billet Aluminum Covers with self-locking set screws
- Hex key wrench

### **Tools you will need to provide:**

- (No additional tools required.)

### **Installation Procedure:**

Important: You do not need to add any thread locking compound (such as Loctite) since these are special self-locking set screws.)

The covers are identical, but with the Harley *Sportster*, the right side is a round rod with a hole through it, the left is a large Hex nut.

If the cover is going over a Hex head bolt or nut, or there is a flat surface on a round rod, it is important to be sure that the setscrew is centered over one of the flat surfaces. Slide the chrome cover over the nut/ axle. So it will be less noticeable, where possible we recommend orienting the cover so the setscrew faces downward.

Make sure you tighten the screws well.

Caring for the covers: Only use cleaner and polisher that is rated as safe for chrome surfaces.