

Installation Instructions for: Chrome Accent

Please follow these instructions carefully!

Package Contents

- Adhesive ABS Chrome Accent
- Alcohol wipe

Tools you will need to provide:

- No tools are needed, however masking tape might be helpful with initial placement. (As explained below.)

These Chrome Accents are made to mount on hard finish, flat surfaces. They flex very little, which is why the mounting surface must be flat!

Installation Procedure: (Read the entire procedure first, before beginning.)

1. Clean the area where you will be mounting the accent with mild detergent to remove any dirt, grease, or wax.
2. Take the chrome accent (with the adhesive film protector still in place) and hold it against the cover so you can decide the best way to locate and orient it. Once you are happy with the placement, put a piece of masking tape along each edge of the ornament so that you will be able to place it in the exact position when the protective film is peeled off.

These chrome accents must be installed at a temperature above 60 degrees F:

The adhesive on the chrome accent is very strong, but initially it will not activate (it will not seem sticky) if the part you are adhering it to is too cold. Once it has adhered, the bond becomes very strong after about 20 minutes. It reaches its maximum strength after 24 hours and can withstand any range of normal riding temperatures from -40 deg F. to 180 deg F.

3. Use the alcohol wipe to do a final cleaning of the area where you will put the accent. Make sure the alcohol dries off before continuing with the next step.
4. Now remove the thin plastic film completely from the back of the ornament. Hold it by the edges and lightly touch it to the mounting surface. If you put it in the wrong place, carefully pull it back off. Once you are happy with its location, press firmly against the ornament and hold for 2 or 3 minutes. Wait at least 20 min. before taking the bike out on the streets.

Now take your bike out for a ride to your friend's house and see if he notices the cool new addition!

Removing the adhesive décor:

If you have mounted it on a hard painted, or chrome surface, you can use a mild solvent such as "Prep-All" (available in the auto body section of Wal-Mart) to loosen the adhesive bond first. You can use a small brush to dab some around the ornament. Wait a minute or two for the solvent to soak in, and then carefully peel off the ornament. Any adhesive residue left on the paint can be removed with a little "Prep-All" on a soft cloth.

If you remove the accent after a long time, it will likely not be possible to re-install it. (You would have to purchase some double-sided tape.)