

Installation Instructions for: Headlight Visor

These instructions are primarily provided for Honda Sabre owners, but the general procedure should be similar for many bikes.

Package Contents

- Chrome Headlight Visor

Tools you will need to provide:

- Philips screwdriver, 8mm, or 5/16 wrench, or small adjustable wrench

Installation Procedure: (Please read over the entire procedure before beginning.)



1. Stand your bike upright, turn on your headlight and note where it is aimed.
2. Remove the two screws (8mm) that attach the front of the headlight assembly to the housing. (A threaded plug may come out as well.) Carefully pull away the headlight assembly.
3. With one hand holding the headlight assembly, use the other hand to disconnect the power plug from the bulb. (It may be a little hard to pull off.)
4. Place the headlight assembly on a soft surface and remove the two Philips head screws on the left and right sides of the assembly. (The screws and the nuts will come off.)
5. Now tilt the front rim forward a little to allow you to insert the headlight visor. Roughly center the visor over the headlight. (You will be able to slide it a little once the headlight is re-assembled.) Then push the rim back where it came from and align the holes for the two screws you removed.
6. Insert the screws into the nuts (flat side of nut is against the housing frame) and tighten.
7. Reattach the power plug into the bulb connector. (Make sure it is completely seated.)
8. Now insert the headlight into the housing, and tighten the screws.
9. You may move the visor in and out a little, or from side to side to achieve the look you desire. (There should be sufficient drag on the visor to maintain it in the position you desire.)
10. Now once again, stand your bike upright, turn on your headlight and make sure it is aimed at the same spot you noted in Step 1. If not, check to make sure that the visor is not binding in the headlight housing which could prevent the headlight from returning to its original alignment.