

## Installation Instructions for: Raider Neck Cover

**Package Contents:** Neck Covers (pair), Allen wrench

**Tools you will need to provide:** (none)

**For Chrome Covers: Do not remove surface protector sheet until installation is complete!**

### **Installation Procedure:**

1. To give yourself more room to work, turn the handlebars away from the side you will be working on.



2. Using the included wrench, remove the two screws that hold the plastic cover in place. (Do not remove the plastic over when you remove the screws.)



3. Take the cover and slip the top edge underneath the rubber trim strip at the top of the neck area.
4. Line up the holes in the neck cover with the holes in the neck and re-insert the screws. (You will have to put a little pressure on the screws as you turn the wrench. If the screw doesn't seem to want to go in, try adjusting the angle of the screw a little in each direction. Get both screws started before tightening.
5. Before tightening the screws, look at the overall fit of the cover on the neck area. The cover is made with slotted holes, which allow you to slightly adjust the positioning of the cover by grasping and gently moving.

6. Once you are satisfied with the look of the cover, tighten the screws until they are snug. **Do not over-tighten or you may distort the surface of the cover.**

**Cleaning the covers:** For the chrome covers, use any wax or cleaner recommended for chrome surfaces. For painted covers, use any cleaner or automotive wax products.