
Installation Instructions for: Seat / Fender Ornament**Please follow these instructions carefully!****Package Contents**

- Seat / Fender Ornament
- Special Adapter Rod
- Allen wrench

Tools you will need to provide:

- Medium Philips Screwdriver (For Harley-Davidson installations)
- 10mm wrench (for Honda Shadow installation. This wrench is included in the factory toolkit.)
- Medium Flat Blade screwdriver (All installations)

Installation Procedure:

1. Using the Philips screwdriver (or 10mm wrench), remove the rear seat mounting screw or nut. (Save this screw or nut in your factory tool kit.) If there is a factory washer against the fender, leave it there.
2. Using the Flat Blade screwdriver, insert the Special Adapter Rod and tighten. (Careful not to over-tighten)
3. Slide the Seat Ornament over the Special Adapter Rod, and orient it as desired.
4. Use the included allen wrench and tighten the set-screw(s) at the base of the ornament. Note: Don't worry if you cannot tighten all of the screws because of interference with the seat. The ornament will stay in place even if only one screw is tightened.

Now take your bike out for a ride to your friend's house and see if he notices the cool new addition!