

Installation Instructions for: Universal Fork Spikes/ Bullets

Package Contents: ABS Chrome Spikes (pair), Alcohol wipe

Tools you will need to provide: None

Installation Procedure:

Important: This product is attached using an industrial quality adhesive foam tape that can only be applied at temperatures above 60 degrees F. If your bike has been out in the cold, you must warm up the forks before attempting to install these spikes. Once the spikes are installed, it is OK if the temperature drops. However, very cold temperatures could cause the bond to strengthen more slowly.

As long as your bike is warm enough, proceed with the following installation steps.



1. Clean the bottom of the fork to remove any mud, grease, etc. using some type of household cleaner. Next use the included alcohol wipe to give a final cleaning to the bottom of the fork. Now wait a couple of minutes for the alcohol to completely evaporate.

2. Remove the protective plastic covering from the adhesive tape and slowly bring it to the bottom of the spike doing a visual alignment. Touch it **very lightly** to the bottom of the fork to create a weak bond. Look at the spike from all angles to check your initial alignment. If you are not satisfied, gently tip the spike and it should come off without too much difficulty.



3. Once you are happy with the appearance, push the spike up against the bottom of the fork and hold it for about 10 seconds under pressure. (The bond gets stronger and stronger as the adhesive cures over the next 24 hours, though you only need to wait about 30 minutes before use.)

Wait: Before taking your bike out to show off your new chrome, wait about 30 minutes for the adhesive bond to reach sufficient strength.

Cleaning the spike: Do not use any abrasive cleaners on the spike. You may clean it with soap and water or use non-abrasive wax products intended for chrome surfaces.